

Door Frame for Craft Hut Canopy

Instructions for Assembly

Parts:

- (1) Craft Hut Lower Leg 45 3/8 in.
- (1) Craft Hut Leg Top for Door Frame - Swaged, 49 1/4 in.
- (1) Female pole 22 1/2"
- (1) Foot AT211
- (1) Door Ell Joint LDRD 202
- (2) StaBar Ell Joints AT202



Assembly:

- 1. While assembling your Craft Hut Canopy:** Slide the Door Ell Joint onto the rear upper horizontal pole of the roof frame, positioning approximately 3 feet from corner.
- 2. Slide StaBar Joints onto leg bottoms:** a StaBar 3-way in the rear corner farthest from the door, a StaBar Ell in the rear corner with the doorway, and a StaBar ell (and foot) on the Rear Door Leg.
- 3. Finish assembling your canopy.** Once you have all four corner legs attached, insert the fifth leg into the Door Ell Joint.
- 4. Assemble the StaBars,** making one of them at 7ft long by using a standard no-color code male pole and the 22 1/2" female pole. Starting with the back wall (7ft StaBar), attach the StaBars to their joints, adjusting the Rear Door Leg position as needed to meet the StaBar at a ninety degree angle.

