

StaBar Set for the TrimLine Canopy

Instructions for use

Parts:

- (3) 61" Male pole sections
- (3) 58 1/4" Female pole sections
- (2) StaBar Ell Joints
- (2) StaBar 3-Way Joints
- (2) Ball Bungees for bundling poles
- (10) Thumbscrews



StaBar 3-Way



StaBar Ell

1. While assembling your TrimLine Canopy: Slide StaBar Joints onto leg bottoms, followed by feet. Do not tighten thumbscrews yet. Check that you have a 3-Way Joint on each back leg and an Ell Joint on each front leg before completing set up of the canopy.

***Note:** If you are installing StaBars for use with MeshPanels, the white arrows on the joints should point down.

2. Once canopy set-up is complete, click together the male and female pole sections to form 3 poles that are 116 1/2" long. These are your StaBars.

3. Beginning with the rear wall, install StaBars by clicking the poles into the StaBar Joints, adjusting the space between the legs as needed. You may also need to adjust the height of the joints to keep the StaBars level. Once they are in the correct position, use the thumbscrews to secure them there.

4. With all three StaBars installed, tighten all thumbscrews on the StaBar Joints.

