

Single StaBar for the TrimLine Canopy

Instructions for use

Parts:

- (1) 61" Male pole sections
- (1) 58 ¼" Female pole sections
- (2) StaBar Ell Joints



StaBar Ell

1. While assembling your TrimLine Canopy: Slide StaBar Ell Joints onto leg bottoms, followed by feet. Do not tighten thumbscrews yet.

***Note:** If you are installing StaBars for use with MeshPanels, the white arrows on the joints should point down.

2. Once canopy set-up is complete, click together the male and female pole sections to form a pole that is 116 ½" long. This is your StaBar.

3. Install StaBar by clicking the poles into the StaBar Ell Joints, adjusting the space between the legs as needed. You may also need to adjust the height of the joints to keep the StaBar level. Once they are in the correct position, use the thumbscrews to secure them there.



StaBar Ell

StaBar Ell

Leg

StaBar Joint

Foot

