


Sidewalls for EZ Up and other Pop Up Canopies

1. Roll up corners of canopy roof to access the frame from the outside of the tent.



*Orienting the walls: grommets are located at the bottom edge and straps are at the top edge.

2. Attach to wall to the outside of the canopy frame using the Velcro straps at the Xs of the frame and Buckle straps at the center and ends. Adjust Buckle straps to keep the top edge of the wall level.



3. Roll down canopy roof corners to cover top edge of wall.



*SideWalls zip to each other for weather protection.

*If you choose to roll your walls up during the day, secure them with the Snap straps at the top edge of the wall.

*Use the Velcro WindStraps to attach the walls to the legs.